



Bilteman tape
For marking in labs

No left over glue on bottles



Hot air sterilization tape
is used
On bottles
to be autoclaved

New rolls are available
from the DWA unit



Steam sterilization tape or the usual painters tape

Do not use for marking of the bottles
→ lots of left over glue on bottles



Can be used only on alufoil!



Scander Extra Cleaner solution available from the DWA unit in Kieppi

For removal of marker pen writings and tape left overs